

# FRC couplings

With a higher load capacity than jaw couplings and maintenance-free operation, FRC couplings are designed as a general purpose coupling. They are able to cushion moderate shock loads, dampen low levels of vibration and accommodate incidental misalignment. FRC couplings offer a range of hubs and elements to select, to meet the demand for low cost, general purpose flexible coupling.

FRC couplings are phosphate coated for improved corrosion resistance and available with fire-resistant and anti-static elements (F.R.A.S.) FRC couplings are available with a pilot bore, finished bore or taper bushing (face or hub) to make installation quick and simple.

Fully machined outside surfaces allow alignment with a simple straight edge. Shaft connections are “fail safe” due to their interlocking jaw design.

## Selection

### 1 Service factor

Determine the required service factor from **tables 9 and 10** on **pages 87 and 88**.

### 2 Design power

Multiply normal running power by the service factor. This gives the design power for coupling selection.

### 3 Coupling size

Using **FRC table 1** to find the speed rating for a coupling that has a power that is greater than the design power. The required FRC coupling is listed at the head of the column.

### 4 Bore size

Using the FRC product table on **page 74**, check that the selected flanges can accommodate both the drive and driven shafts.

## Example

An FRC coupling is required to transmit 15 kW from an electric motor running at 500 r/min to a rotary pump for 15 hours per day. The shaft diameter of the motor is 25 mm and the shaft diameter of the pump is 20 mm.

### 1 Service factor

From **table 9** on **page 87** = 1,75.

### 2 Design power

$15 \times 1,75 = 26.25$  kW

Table 1

### Power ratings

Speed	Coupling size							
	70	90	110	130	150	180	230	280
r/min	kW							
50	0.16	0.42	0.84	1.65	3.14	4.97	10.47	16.49
100	0.33	0.84	1.68	3.3	6.28	9.95	20.94	32.98
200	0.66	1.68	3.35	6.6	12.57	19.9	41.88	65.97
300	0.99	2.51	5.03	9.9	18.85	29.84	62.83	98.95
400	1.32	3.35	6.7	13.19	25.13	39.79	83.77	131.94
500	1.65	4.19	8.38	16.49	31.41	49.74	104.71	164.92
600	1.98	5.03	10.05	19.79	37.7	59.69	125.65	197.91
700	2.31	5.86	11.73	23.09	43.98	69.63	146.6	230.89
720	2.37	6.03	12.06	23.75	45.24	71.62	150.79	237.49
800	2.64	6.7	13.4	26.39	50.26	79.58	167.54	263.87
900	2.97	7.54	15.08	29.69	56.54	89.53	188.48	296.86
960	3.17	8.04	16.08	31.66	60.31	95.5	201.05	316.65
1000	3.3	8.38	16.75	32.98	62.83	99.48	209.42	329.84
1200	3.96	10.05	20.1	39.58	75.39	119.37	251.31	395.81
1400	4.62	11.73	23.46	46.18	87.96	139.27	293.19	461.78
1440	4.75	12.06	24.13	47.5	90.47	143.25	301.57	474.97
1600	5.28	13.4	26.81	52.77	100.52	159.16	335.08	527.75
1800	5.94	15.08	30.16	59.37	113.09	179.06	376.96	593.72
2000	6.6	16.75	33.51	65.97	125.65	198.95	418.85	659.69
2200	7.26	18.43	36.86	72.57	138.22	218.85	460.73	725.65
2400	7.92	20.1	40.21	79.16	150.79	238.74	502.62	—
2600	8.58	21.78	43.56	85.76	163.35	258.64	544.5	—
2800	9.24	23.46	46.91	92.36	175.92	278.53	—	—
2880	9.5	24.13	48.25	94.99	180.94	286.49	—	—
3000	9.9	25.13	50.26	98.95	188.48	298.43	—	—
3600	11.87	30.16	60.31	118.74	226.18	—	—	—
Nominal torque Nm	31	80	160	315	600	950	2000	3150
Max. torque Nm	72	180	360	720	1500	2350	5000	7200

### 3 Coupling size

Search for 500 r/min in **table 1** on **page 71** and choose the first power figure which exceeds the required 26.25 kW. This is 31.41 kW of coupling size 150.

### 4 Bore size

By referring to product table on **page 74**, it can be seen that both shaft diameters fall within the bore range available.

tion using the formula below and select a coupling based on the nominal torque rating.

$$\text{Nominal torque (Nm)} =$$

$$\frac{\text{Design power (kW)} \times 9\,550}{\text{r/min}}$$

For additional information on FRC couplings, refer to **tables 1** and **2**.

## Engineering data

### Power ratings

Maximum torque figures should be treated as short duration overload ratings occurring in circumstances such as direct-on-line starting.

For speeds not shown, calculate the nominal torque for the design applica-

## Order data

A complete FRC coupling consists of: 2 hubs and 1 element.

For more detailed information on ordering specific couplings, refer to **table 3**.

Table 2

### Assembled dimensions and characteristics

Size	Assembled length comprising flange types			Mass <sup>1)</sup>	Inertia	Torsional stiffness	Misalignment			Nominal torque	Torque Max.
	FF. FH. HH	FB. HB	BB				Angular	Parallel	Axial		
–	mm			kg	kg/m <sup>2</sup>	Nm/°	°	mm		Nm	–
70	65.0	65.0	65.0	1.00	0.00085	–	1	0.3	0.2	31.5	72
90	69.5	76.0	82.5	1.17	0.00115	–	1	0.3	0.5	80	180
110	82.0	100.5	119.0	5.00	0.0040	65	1	0.3	0.6	160	360
130	89.0	110.0	131.0	5.46	0.0078	130	1	0.4	0.8	315	720
150	107.0	129.5	152.0	7.11	0.0181	175	1	0.4	0.9	600	1500
180	142.0	165.5	189.0	16.60	0.0434	229	1	0.4	1.1	950	2350
230	164.5	202.0	239.5	26.00	0.1207	587	1	0.5	1.3	2 000	5 000
280	207.5	246.5	285.5	50.00	0.4465	1025	1	0.5	1.7	3 150	7 200

<sup>1)</sup> Mass is for an FF, FH or HH coupling with mid range tapered bushings.

Table 3

### Order data

Coupling type	Flanges	Qty	Element	Qty	Taper bushing	Qty
RSB both sides	PHE FRC70RSB	2	PHE FRC70NR or	1	–	–
	–	–	PHE FRC70FR	–	–	–
RSB/F Combination	PHE FRC70RSB	1	PHE FRC70NR or	1	PHF TB1008X...MM	1
	PHE FRC70FTB	1	PHE FRC70FR	–	–	–
RSB/H Combination	PHE FRC70RSB	1	PHE FRC70NR or	1	PHF TB1008X...MM	1
	PHE FRC70HTB	1	PHE FRC70FR	–	–	–
F/F Combination	PHE FRC70FTB	1	PHE FRC70NR or	1	PHF TB1008X...MM	1
	PHE FRC70FTB	1	PHE FRC70FR	–	PHF TB1008X...MM	1
H/H Combination	PHE FRC70HTB	1	PHE FRC70NR or	1	PHF TB1008X...MM	1
	PHE FRC70HTB	1	PHE FRC70FR	–	PHF TB1008X...MM	1
F/H Combination	PHE FRC70FTB	1	PHE FRC70NR or	1	PHF TB1008X...MM	1
	PHE FRC70HTB	1	PHE FRC70FR	–	PHF TB1008X...MM	1


NR = Nitrile rubber  
FR = Fire-resistant and anti-static (FRAS)


# Installation

- 1 Place the couplings on their shafts so that shaft ends do not protrude into the internal section of the coupling. Then tighten the screws on the taper bushing to the torque values listed in the mounting instructions (→ fig. 1).
- 2 Insert the coupling element into one side of the coupling (→ fig. 2).
- 3 Move the other coupling into position and connect the two halves (→ fig. 4). Check that the assembled length is correct (→ fig. 5).
- 4 Check angular misalignment by measuring the assembled length in four positions at 90° around the coupling. Then check for parallel misalignment using a straight edge across the length of the coupling flange (→ fig. 6). Allowable angular misalignment for all FRC couplings is 1°. Allowable parallel misalignment for FRC couplings is based on size (→ table 4).


**Note:** For the most consistent results, check across at least 3 of the 6 points where the rubber elements are visible between the flanges.

Allowable parallel misalignment	
Coupling size	mm
FRC70 to 110	0.3
FRC130 to 180	0.4
FRC230 to 280	0.5






Type B



Type F



Type H

Coupling size	Dimensions		Type F, H Bushing size	Bore		C	D	J <sup>1)</sup>	Type B			C	D	Hub designation		
	OD	H		Min.	Max.				Bore Max	Pilot bore	Key screw			Type F	Type H	Type B Pilot bore
– mm																
70	69	60	1008	9	25	20	23.5	29	32	10	M6	20	25.8	PHE FRC70FTB	PHE FRC70HTB	PHE FRC70RSB
90	85	70	1108	9	28	19.5	23.5	29	38	10	M6	26	30.0	PHE FRC90FTB	PHE FRC90HTB	PHE FRC90RSB
110	112	100	1610	14	42	18.5	26.5	38	55	10	M10	37	45.3	PHE FRC110FTB	PHE FRC110HTB	PHE FRC110RSB
130	130	105	1610	14	42	18	26.5	38	60	20	M10	39	47.5	PHE FRC130FTB	PHE FRC130HTB	PHE FRC130RSB
150	150	115	2012	14	50	23.5	33.5	42	70	28	M10	46	60.0	PHE FRC150FTB	PHE FRC150HTB	PHE FRC150RSB
180	180	125	2517	16	60	34.5	46.5	48	80	28	M10	58	70.0	PHE FRC180FTB	PHE FRC180HTB	PHE FRC180RSB
230	225	155	3020	25	75	39.5	52.5	55	100	45	M12	77	90.0	PHE FRC230FTB	PHE FRC230HTB	PHE FRC230RSB
280	275	206	3525	35	100	51	66.5	67	115	55	M16	90	105.5	PHE FRC280FTB	PHE FRC280HTB	PHE FRC280RSB

<sup>1)</sup> Clearance required for tightening/loosening the bushing on the shaft